

Magnetic Base

What it is

The magnetic base is used to temporarily secure "magnetic system" diamond abrasive discs and polishing cloths to a platen. It may also be used in conjunction with magnetic Stainless Steel Support Plates, onto which adhesive backed products are adhered.

How to use

Thoroughly clean the platen surface onto which the magnetic base will be attached using acetone or isopropyl alcohol to remove any dirt or debris.

Remove the protective adhesive liner from the magnetic base and carefully apply to the platen so that no bubbles form between it and the platen surface.

Apply the magnetic system disc to the magnetic base and remove by simply lifting it from one edge.

Maintenance

Periodically, it is necessary to clean and wipe the magnetic base free of abrasive particles and suspensions. Rinse with water until it is clean. Dry with air, if possible, or a lint free towel.

Replace if the disc shows signs of wear to ensure maximum performance.

8", # 90-208300

10", # 90-208302

12", # 90-208305